

Mobile Re-Provision How to Guide

Contents

- 1 Overview
- 2 Mobile Provision, Re-Provision and ResetPIN software
- 3 Installing ResetPIN
- 4 Connecting to Provision
- 5 Configuring PINsafe to allow Mobile Re-Provision
- 6 Default Configuration files
- 7 ResetPIN options explained
- 8 Mobile Re-Provision Sample
- 9 Known Issues
- 10 Troubleshooting Mobile Re-provision

Overview

For the Mobile Provision user guide see [Mobile Provision User Guide](#)

A Mobile Phone user may request a Mobile Provision Code to allow their Mobile Phone Client to download security strings. The Swivel Helpdesk or Administrator can send the user a Site ID email or SMS message from Swivel version 3.9.7.

The [User Portal](#) and Reset Utility provide additional functionality of a self provision and re-provision of mobile clients. This document outlines how to configure the reset.war utility that provides Mobile Phone Provision and Re-Provision. Use of the [User Portal](#) should be considered over the ResetPIN and Re-Provision utility.

Also see [Mobile Provision Code](#)

Mobile Provision, Re-Provision and ResetPIN software

The ResetPIN software can be downloaded from [here](#)

Installing ResetPIN

ResetPIN is already installed on the virtual or hardware Appliances in the webapps2 folder. If it is virtual or hardware appliance version 2.0.12 or earlier then the ResetPIN software will need to be upgraded, see [ResetPIN upgrade for PINsafe 3.8 How To Guide](#).

To install extract from the zip file and copy the resetpin.war file to the webapps or for virtual or hardware appliances the webapps2 folder. It will automatically deploy when Tomcat is running.

Connecting to Provision

Virtual or hardware appliance: <https://IP:8443/resetpin/provision.jsp>

software install: <http://IP:8080/resetpin/provision.jsp>

Configuring PINsafe to allow Mobile Re-Provision

Swivel must be configured to allow the Mobile Re-Provision utility. On the Swivel Administration console select Policy/Self-Reset then Allow User self-provision of mobile client: to Yes

Send provision code as security string: Yes/No. If set to Yes, then the users provision code will be sent by their security string transport instead of their Alert transport.

Default Configuration files

On a virtual or hardware appliance the file is located at:

/usr/local/apache-tomcat-5.5.20/webapps2/resetpin/WEB-INF/settings.xml

The configuration of ResetPIN is in the file settings.xml with the following default values

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE properties SYSTEM "http://java.sun.com/dtd/properties.dtd">
<properties>
<entry key="ssl">false</entry>
<entry key="server">localhost</entry>
<entry key="port">8181</entry>
<entry key="context">pinsafe</entry>
<entry key="secret">secret</entry>
<entry key="redirect">http://www.swivelsecure.com</entry>
</properties>
```

ResetPIN options explained

The options configure both ResetPIN and the Re-Provision.

ssl: true/false, for communication between ResetPIN and the Swivel server

server: the Swivel server hostname for IP address, for communication between ResetPIN and the Swivelserver

port: the port used to communicate with the PINsafe server for IP address, for communication between ResetPIN and the Swivel server. For software installations use 8080, for virtual or hardware appliances where webapps2 is used, the port 8181 should be used.

context: the install name of the Swivel application, usually pinsafe for IP address, for communication between ResetPIN and the Swivel server

secret: the shared secret, must also be entered under Server/Agent on the Swivel console for IP address, for communication between ResetPIN and the Swivel server

redirect: redirects on completion of ResetPIN, remove the line for no redirect, this must be an address users can get to

Mobile Re-Provision Sample

Browse to the Provision link



A screenshot of a web form for mobile re-provisioning. It features a label "Username:" followed by a text input field. Below the input field is a button labeled "Provision". The entire form is enclosed in a light gray border.

Enter username



A screenshot of the same web form as above, but now the text input field contains the username "gfield". The "Provision" button remains visible below the field.

Click on Provision



A screenshot of the web form after the "Provision" button has been clicked. The text "Provision Code Sent" is now displayed in the bottom left corner of the form area. The "Username:" label and the "gfield" text in the input field are still visible, along with the "Provision" button.

User should receive by their pre-defined transport method a Mobile Provision Code to be entered on the Mobile Phone Applet

Example: Mobile provision code: 4835607192

Known Issues

Troubleshooting Mobile Re-provision

User not set

No username has been entered under options. Enter the username and retry.

Check the Swivel logs

Agent Error Message: **Provision Code failedAGENT_ERROR_PROVISION_DISABLED**

Swivel log message: **Provision code failed for user "username", AGENT_ERROR_PROVISION_DISABLED**

Username:

gfield

Provision

Provision Code failedAGENT_ERROR_PROVISION_DISABLED

The self Provision is not enabled. On the Swivel Administration Console select Policy/Self-Reset then Allow User self-provision of mobile client: to Yes