

OpenManage

Contents

- [1 Overview](#)
- [2 Prerequisites](#)
- [3 How to Disable OpenManage](#)
- [4 Testing](#)
- [5 Known Issues](#)
- [6 Troubleshooting](#)

Overview

OpenManage is a set of tools on the Swivel Dell Hardware Appliances from appliance version 2.0.10 onwards. OpenManage uses port 1311.

Prerequisites

Swivel Hardware appliance 2.0.10 onwards.

How to Disable OpenManage

from the command line run;

```
/opt/dell/srvadmin/sbin/srvadmin-services.sh disable
```

Testing

Known Issues

Troubleshooting